



Kinematic analysis of rigid-link Spatial Mechanisms




Basics of Mechanism

Classification of Mechanism


Planar Mechanism

All the points of a mechanism move in parallel planes

Closed Chain




Open Chain



Spatial Mechanism

All the points of a mechanism do not move in parallel planes

Closed Chain



Open Chain






Spatial Geometry



Fundamentals of Spatial Geometry

Description of a POINT in space



RH Cartesian coordinate system or
RH frame






Fundamentals of Spatial Geometry



Description of a POINT in space

Representation in Cartesian Coordinate system



$${}^1\mathbf{P} = {}^1p_x\hat{\mathbf{i}} + {}^1p_y\hat{\mathbf{j}} + {}^1p_z\hat{\mathbf{k}}$$

$${}^1\mathbf{P} = \begin{bmatrix} {}^1p_x \\ {}^1p_y \\ {}^1p_z \end{bmatrix} = [{}^1p_x \quad {}^1p_y \quad {}^1p_z]^T$$

where ${}^1p_x, {}^1p_y, {}^1p_z$ are the components of the vector $\overrightarrow{OP}$ along the three coordinate axes or the projections of the vector $\overrightarrow{OP}$ on the axes X, Y, Z, respectively.

$$\cos \alpha = \frac{{}^1p_x}{L}, \cos \beta = \frac{{}^1p_y}{L}, \cos \gamma = \frac{{}^1p_z}{L}$$

$$L = |\vec{P}| = |\overrightarrow{OP}| = \sqrt{({}^1p_x)^2 + ({}^1p_y)^2 + ({}^1p_z)^2}$$

where α, β , and γ are, respectively, the right handed angles measured from the coordinate axes to the vector $\overrightarrow{OP}$, which has a length L .



Description of a POINT in space



Representation in Homogeneous Coordinate

In homogeneous co-ordinate, a point 'P' in Space (3-D) is denoted as

$$\vec{P} = \begin{bmatrix} x' \\ y' \\ z' \\ \sigma \end{bmatrix} \quad P = \begin{bmatrix} (\sigma \cdot h_x) \\ (\sigma \cdot h_y) \\ (\sigma \cdot h_z) \\ \sigma \end{bmatrix} \Rightarrow 4 \times 1 \text{ matrix } (N+1) \text{ th.}$$

- the fourth component ' σ ' is a non-zero positive scaling factor.

The physical co-ordinates in Cartesian representation are obtained by dividing each component in homogeneous representation by the scaling factor.

If the value of the scaling factor (σ) is set to '1', the components of homogeneous & Cartesian representation are identical.



Description of a POINT in space



Representation in Homogeneous Coordinate

In homogeneous co-ordinate, a point 'P' in Space (3-D) is denoted as

$$\vec{P} = \begin{bmatrix} x' \\ y' \\ z' \\ \sigma \end{bmatrix}$$

$${}^1P = \begin{bmatrix} (\sigma' p_x) \\ (\sigma' p_y) \\ (\sigma' p_z) \\ \sigma \end{bmatrix}$$

$\Rightarrow 4 \times 1$ matrix $(N+1) \times 1$

- the fourth component ' σ ' is a non-zero positive scaling factor.

For example: Physical position vector


$$\vec{P} = 3\hat{i} - 2\hat{j} + 4\hat{k}$$
$$= \begin{bmatrix} 3 \\ -2 \\ 4 \end{bmatrix}$$

In homogeneous co-ordinate

$\vec{P}$ equivalent to $\vec{P}_1 = \begin{bmatrix} 3 \\ -2 \\ 4 \\ 1 \end{bmatrix}$ with $\sigma = 1$ (Same as physical co-ordinate)

$$= \begin{bmatrix} 6 \\ -4 \\ 8 \\ 2 \end{bmatrix} \text{ with } \sigma = 2$$

$$= \begin{bmatrix} 1.5 \\ -1 \\ 2 \\ 0.5 \end{bmatrix} \text{ with } \sigma = 0.5$$








Mapping



Mapping

refers to changing the description of a POINT (or a vector) from one coordinate system (i.e. frame) to another coordinate system (i.e. frame).

Second coordinate frame has THREE possibilities in relation to the first coordinate frame

(i)	Second coordinate frame is rotated w.r.to the first but origin of both the frames is same	Mapping between Rotated frame	
(ii)	Second coordinate frame is moved away from first, the axes of both frames remains parallel. This is a translation of the origin of the second frame from the first frame.	Mapping between Translated frame	
(iii)	Second coordinate frame is rotated as well as translated	Mapping between Rotated & Translated frame	



Mapping



Mapping between Rotated Frame

Second coordinate frame is rotated w.r.to the first but origin of both the frames is same




Consider a rigid body 'S' to which a Co-ordinate frame $\{2\}$ with axes $\{x_2, y_2, z_2\}$ is attached. Frame $\{2\}$ is a body attached frame.

We wish to relate the Co-ordinates of a point 'P' on rigid body S in frame $\{2\}$ to the Co-ordinates of 'P' in a fixed reference frame $\{1\}$.

Both the frame $\{1\}$ & $\{2\}$ share a common origin.

A point 'P' in Space can be described by the two frames $\{1\}$ & $\{2\}$ can be expressed as vectors 1P and 2P

$$\begin{aligned} \text{w.r.to frame } \{1\} \rightarrow {}^1P &= {}^1p_x \hat{i}_1 + {}^1p_y \hat{j}_1 + {}^1p_z \hat{k}_1 & \text{or } {}^1P &= \begin{bmatrix} {}^1p_x \\ {}^1p_y \\ {}^1p_z \end{bmatrix} \\ \text{w.r.to frame } \{2\} \rightarrow {}^2P &= {}^2p_x \hat{i}_2 + {}^2p_y \hat{j}_2 + {}^2p_z \hat{k}_2 & \text{or } {}^2P &= \begin{bmatrix} {}^2p_x \\ {}^2p_y \\ {}^2p_z \end{bmatrix} \end{aligned}$$



$$\cos \alpha = \frac{{}^1p_x}{L}, \cos \beta = \frac{{}^1p_y}{L}, \cos \gamma = \frac{{}^1p_z}{L}$$

$$L = |\vec{P}| = |\overrightarrow{OP}| = \sqrt{({}^1p_x)^2 + ({}^1p_y)^2 + ({}^1p_z)^2}$$




Mapping



Mapping between Rotated Frame

Second coordinate frame is rotated w.r.to the first but origin of both the frames is same



Since 1P & 2P are representations of the same vector $\vec{OP}$, the relationship betⁿ the components of $\vec{OP}$ in the two co-ordinate frames can be obtained.
 ${}^1P = \vec{OP}$ and ${}^2P = \vec{OP}$

1st Problem

Aim: The description of point 'P' in frame {2} is known & its description in frame {1} is to be found.

$$\left[\begin{aligned} {}^1P_x &= |{}^1P| |\hat{e}_1| \cos \alpha \quad (\leftarrow {}^1P \cdot \hat{e}_1) \\ &= |{}^1P| \cos \alpha. \end{aligned} \right]$$

$${}^1P_y = {}^1P \cdot \hat{e}_2 = |{}^1P| |\hat{e}_2| \cos \beta$$

$${}^1P_z = |{}^1P| |\hat{e}_3| \cos \gamma$$

$${}^1P_z = |{}^1P| |\hat{e}_3| \cos \gamma$$

$$\cos \alpha = \frac{{}^1P_x}{L}, \cos \beta = \frac{{}^1P_y}{L}, \cos \gamma = \frac{{}^1P_z}{L}$$

$$L = |\vec{P}| = |\vec{OP}| = \sqrt{({}^1P_x)^2 + ({}^1P_y)^2 + ({}^1P_z)^2}$$

$$\begin{aligned}
 {}^1p_x &= {}^1p \cdot \hat{i}_1 = {}^2p \cdot \hat{i}_1 = ({}^2p_x \hat{i}_2 + {}^2p_y \hat{j}_2 + {}^2p_z \hat{k}_2) \cdot \hat{i}_1 = {}^2p_x \hat{i}_2 \cdot \hat{i}_1 + {}^2p_y \hat{j}_2 \cdot \hat{i}_1 + {}^2p_z \hat{k}_2 \cdot \hat{i}_1 \\
 {}^1p_y &= {}^1p \cdot \hat{j}_1 = {}^2p \cdot \hat{j}_1 = ({}^2p_x \hat{i}_2 + {}^2p_y \hat{j}_2 + {}^2p_z \hat{k}_2) \cdot \hat{j}_1 = {}^2p_x \hat{i}_2 \cdot \hat{j}_1 + {}^2p_y \hat{j}_2 \cdot \hat{j}_1 + {}^2p_z \hat{k}_2 \cdot \hat{j}_1 \\
 {}^1p_z &= {}^1p \cdot \hat{k}_1 = {}^2p \cdot \hat{k}_1 = ({}^2p_x \hat{i}_2 + {}^2p_y \hat{j}_2 + {}^2p_z \hat{k}_2) \cdot \hat{k}_1 = {}^2p_x \hat{i}_2 \cdot \hat{k}_1 + {}^2p_y \hat{j}_2 \cdot \hat{k}_1 + {}^2p_z \hat{k}_2 \cdot \hat{k}_1
 \end{aligned}$$



Mapping



Mapping between Rotated Frame

Second coordinate frame is rotated w.r.to the first but origin of both the frames is same

1st Problem

Aim: The description of point 'P' in frame {2} is known & its description in frame {1} is to be found.

$$\begin{aligned} {}^1P_x &= |P| |\hat{e}_1| \cos \alpha \quad (\leftarrow {}^1P \cdot \hat{e}_1) \\ &= |P| \cos \alpha. \end{aligned}$$

$$\begin{aligned} {}^1P_x &= {}^1P \cdot \hat{e}_1 = {}^2P \cdot \hat{e}_1 = ({}^2P_x \hat{e}_2 + {}^2P_y \hat{e}_3 + {}^2P_z \hat{e}_4) \cdot \hat{e}_1 = {}^2P_x \hat{e}_2 \cdot \hat{e}_1 + {}^2P_y \hat{e}_3 \cdot \hat{e}_1 + {}^2P_z \hat{e}_4 \cdot \hat{e}_1 \\ {}^1P_y &= {}^1P \cdot \hat{e}_2 = {}^2P \cdot \hat{e}_2 = ({}^2P_x \hat{e}_2 + {}^2P_y \hat{e}_3 + {}^2P_z \hat{e}_4) \cdot \hat{e}_2 = {}^2P_x \hat{e}_2 \cdot \hat{e}_2 + {}^2P_y \hat{e}_3 \cdot \hat{e}_2 + {}^2P_z \hat{e}_4 \cdot \hat{e}_2 \\ {}^1P_z &= {}^1P \cdot \hat{e}_3 = {}^2P \cdot \hat{e}_3 = ({}^2P_x \hat{e}_2 + {}^2P_y \hat{e}_3 + {}^2P_z \hat{e}_4) \cdot \hat{e}_3 = {}^2P_x \hat{e}_2 \cdot \hat{e}_3 + {}^2P_y \hat{e}_3 \cdot \hat{e}_3 + {}^2P_z \hat{e}_4 \cdot \hat{e}_3 \end{aligned}$$

$$\begin{bmatrix} {}^1P_x \\ {}^1P_y \\ {}^1P_z \end{bmatrix} = \begin{matrix} x_2 & y_2 & z_2 \\ \hat{e}_2 \cdot \hat{e}_1 & \hat{e}_3 \cdot \hat{e}_1 & \hat{e}_4 \cdot \hat{e}_1 \\ \hat{e}_2 \cdot \hat{e}_2 & \hat{e}_3 \cdot \hat{e}_2 & \hat{e}_4 \cdot \hat{e}_2 \\ \hat{e}_2 \cdot \hat{e}_3 & \hat{e}_3 \cdot \hat{e}_3 & \hat{e}_4 \cdot \hat{e}_3 \end{matrix} \begin{bmatrix} {}^2P_x \\ {}^2P_y \\ {}^2P_z \end{bmatrix}$$

$${}^1P = {}^1R_2 {}^2P \quad \dots (2) \longrightarrow \text{Compressed vector-matrix notation/form.}$$






Mapping



Mapping between Rotated Frame

Second coordinate frame is rotated w.r.to the first but origin of both the frames is same



$$\begin{bmatrix} {}^1p_x \\ {}^1p_y \\ {}^1p_z \end{bmatrix} = \begin{matrix} x_1 & y_1 & z_1 \end{matrix} \begin{bmatrix} \hat{i}_2 \cdot \hat{i}_1 & \hat{j}_2 \cdot \hat{i}_1 & \hat{k}_2 \cdot \hat{i}_1 \\ \hat{i}_2 \cdot \hat{j}_1 & \hat{j}_2 \cdot \hat{j}_1 & \hat{k}_2 \cdot \hat{j}_1 \\ \hat{i}_2 \cdot \hat{k}_1 & \hat{j}_2 \cdot \hat{k}_1 & \hat{k}_2 \cdot \hat{k}_1 \end{bmatrix} \begin{bmatrix} {}^2p_x \\ {}^2p_y \\ {}^2p_z \end{bmatrix}$$

$${}^1R_2 = \begin{bmatrix} \hat{i}_2 \cdot \hat{i}_1 & \hat{j}_2 \cdot \hat{i}_1 & \hat{k}_2 \cdot \hat{i}_1 \\ \hat{i}_2 \cdot \hat{j}_1 & \hat{j}_2 \cdot \hat{j}_1 & \hat{k}_2 \cdot \hat{j}_1 \\ \hat{i}_2 \cdot \hat{k}_1 & \hat{j}_2 \cdot \hat{k}_1 & \hat{k}_2 \cdot \hat{k}_1 \end{bmatrix} \quad \text{--- (3)}$$

= Rotation Matrix
or
Rotational Transformation
Matrix

- It contains only the dot products of unit vectors of the two frames & is independent of the point 'P'.
- 1R_2 can be used for transformation of the coordinates of any pt. 'P' in frame {2} to frame {1}.



Mapping

Mapping between Rotated Frame

2nd Prob: Aim: 1P = known

$$\begin{bmatrix} {}^1p_x \\ {}^1p_y \\ {}^1p_z \end{bmatrix} = \begin{matrix} x_1 & y_1 & z_1 \end{matrix} \begin{bmatrix} \hat{i}_2 \cdot \hat{i}_1 & \hat{j}_2 \cdot \hat{i}_1 & \hat{k}_2 \cdot \hat{i}_1 \\ \hat{i}_2 \cdot \hat{j}_1 & \hat{j}_2 \cdot \hat{j}_1 & \hat{k}_2 \cdot \hat{j}_1 \\ \hat{i}_2 \cdot \hat{k}_1 & \hat{j}_2 \cdot \hat{k}_1 & \hat{k}_2 \cdot \hat{k}_1 \end{bmatrix} \begin{bmatrix} {}^2p_x \\ {}^2p_y \\ {}^2p_z \end{bmatrix}$$

$${}^2p_x = {}^2P \cdot \hat{i}_2 = {}^1P \cdot \hat{i}_2 = {}^1p_x \hat{i}_1 \cdot \hat{i}_2 + {}^1p_y \hat{j}_1 \cdot \hat{i}_2 + {}^1p_z \hat{k}_1 \cdot \hat{i}_2$$

$${}^2p_y = {}^2P \cdot \hat{j}_2 = {}^1P \cdot \hat{j}_2 = {}^1p_x \hat{i}_1 \cdot \hat{j}_2 + {}^1p_y \hat{j}_1 \cdot \hat{j}_2 + {}^1p_z \hat{k}_1 \cdot \hat{j}_2$$

$${}^2p_z = {}^2P \cdot \hat{k}_2 = {}^1P \cdot \hat{k}_2 = {}^1p_x \hat{i}_1 \cdot \hat{k}_2 + {}^1p_y \hat{j}_1 \cdot \hat{k}_2 + {}^1p_z \hat{k}_1 \cdot \hat{k}_2$$

$$\begin{bmatrix} {}^2p_x \\ {}^2p_y \\ {}^2p_z \end{bmatrix} = \begin{bmatrix} \hat{i}_1 \cdot \hat{i}_2 & \hat{j}_1 \cdot \hat{i}_2 & \hat{k}_1 \cdot \hat{i}_2 \\ \hat{i}_1 \cdot \hat{j}_2 & \hat{j}_1 \cdot \hat{j}_2 & \hat{k}_1 \cdot \hat{j}_2 \\ \hat{i}_1 \cdot \hat{k}_2 & \hat{j}_1 \cdot \hat{k}_2 & \hat{k}_1 \cdot \hat{k}_2 \end{bmatrix} \begin{bmatrix} {}^1p_x \\ {}^1p_y \\ {}^1p_z \end{bmatrix} \quad \text{----- (4)}$$

$${}^2P = {}^2R_1 \cdot {}^1P$$

< pt 'P' in frame $\{1\}$ is transformed to frame $\{2\}$ >

$${}^2R_1 = \begin{bmatrix} \hat{i}_1 \cdot \hat{i}_2 & \hat{j}_1 \cdot \hat{i}_2 & \hat{k}_1 \cdot \hat{i}_2 \\ \hat{i}_1 \cdot \hat{j}_2 & \hat{j}_1 \cdot \hat{j}_2 & \hat{k}_1 \cdot \hat{j}_2 \\ \hat{i}_1 \cdot \hat{k}_2 & \hat{j}_1 \cdot \hat{k}_2 & \hat{k}_1 \cdot \hat{k}_2 \end{bmatrix}$$



Mapping



Mapping between Rotated Frame

$${}^1p = {}^1R_2 \cdot {}^2p$$

$${}^2p = [{}^1R_2]^{-1} \cdot {}^1p$$

$${}^2p = {}^2R_1 \cdot {}^1p$$

$${}^2p = [{}^1R_2]^T \cdot {}^1p$$

$${}^2R_1 = [{}^1R_2]^{-1} = [{}^1R_2]^T$$

$${}^1R_2 = \begin{bmatrix} \hat{i}_2 \cdot \hat{i}_1 & \hat{j}_2 \cdot \hat{i}_1 & \hat{k}_2 \cdot \hat{i}_1 \\ \hat{i}_2 \cdot \hat{j}_1 & \hat{j}_2 \cdot \hat{j}_1 & \hat{k}_2 \cdot \hat{j}_1 \\ \hat{i}_2 \cdot \hat{k}_1 & \hat{j}_2 \cdot \hat{k}_1 & \hat{k}_2 \cdot \hat{k}_1 \end{bmatrix}$$

$$\begin{aligned} {}^2R_1 &= \begin{bmatrix} \hat{i}_1 \cdot \hat{i}_2 & \hat{j}_1 \cdot \hat{i}_2 & \hat{k}_1 \cdot \hat{i}_2 \\ \hat{i}_1 \cdot \hat{j}_2 & \hat{j}_1 \cdot \hat{j}_2 & \hat{k}_1 \cdot \hat{j}_2 \\ \hat{i}_1 \cdot \hat{k}_2 & \hat{j}_1 \cdot \hat{k}_2 & \hat{k}_1 \cdot \hat{k}_2 \end{bmatrix} \\ &= [{}^1R_2]^T \end{aligned}$$

Inverse of Rotation Matrix = Transpose of Rotation Matrix

$$R^{-1} = R^T$$

$\therefore RR^T = I = 3 \times 3$ identity matrix.



Mapping



Properties of Rotation Matrix

1) The inverse of a rotation matrix is the transpose of it

$$R^{-1} = R^T \quad \leftarrow \text{A matrix with this condition is called ORTHOGONAL}$$
$$R R^T = I$$

[Orthogonality of R_2 comes from this fact that it maps an orthogonal coordinate frame to another orthogonal coordinate frame] : Orthogonality property.

2) The determinant of the rotation matrix is unity $\begin{cases} +1 \text{ for RH coord.} \\ -1 \text{ for LH coord.} \end{cases}$

$$\text{i.e., } \begin{vmatrix} r_{11} & r_{12} & r_{13} \\ r_{21} & r_{22} & r_{23} \\ r_{31} & r_{32} & r_{33} \end{vmatrix} = 1$$

3) The dot product of two different rows is zero.
Similarly the dot product of two different columns is zero.

4) The dot product of any row with itself is unity.
Similarly the dot product of any column with itself is unity.

5) The rotation matrices generally don't commute i.e. sequence is important.

$$R_z(\theta) \cdot R_z(\phi) \neq R_z(\phi) R_z(\theta).$$

X



Principle Axis Rotation

Fundamental Rotation Matrix

To determine the orientation of frame $\{2\}$, which is rotated about one of the three principal axes of frame $\{1\}$. Consider the rotation of frame $\{2\}$ w.r. to frame $\{1\}$ by angle ' θ_3 ' about the z' axis of frame $\{1\}$. The corresponding rotation matrix (1R_2) known as the Fundamental Rotation Matrix $R_z(\theta_3)$



$$\begin{bmatrix} {}^1p_x \\ {}^1p_y \\ {}^1p_z \end{bmatrix} = \begin{matrix} x_2 & y_2 & z_2 \\ \begin{bmatrix} \hat{i}_2 \cdot \hat{i}_1 & \hat{j}_2 \cdot \hat{i}_1 & \hat{k}_2 \cdot \hat{i}_1 \\ \hat{i}_2 \cdot \hat{j}_1 & \hat{j}_2 \cdot \hat{j}_1 & \hat{k}_2 \cdot \hat{j}_1 \\ \hat{i}_2 \cdot \hat{k}_1 & \hat{j}_2 \cdot \hat{k}_1 & \hat{k}_2 \cdot \hat{k}_1 \end{bmatrix} \end{matrix} \begin{bmatrix} {}^2p_x \\ {}^2p_y \\ {}^2p_z \end{bmatrix}$$




Fundamental Rotation Matrix

Rotation about Z



$$\begin{bmatrix} {}^1p_x \\ {}^1p_y \\ {}^1p_z \end{bmatrix} = \begin{matrix} x_1 \\ y_1 \\ z_1 \end{matrix} \begin{bmatrix} \hat{i}_2 \cdot \hat{i}_1 & \hat{j}_2 \cdot \hat{i}_1 & \hat{k}_2 \cdot \hat{i}_1 \\ \hat{i}_2 \cdot \hat{j}_1 & \hat{j}_2 \cdot \hat{j}_1 & \hat{k}_2 \cdot \hat{j}_1 \\ \hat{i}_2 \cdot \hat{k}_1 & \hat{j}_2 \cdot \hat{k}_1 & \hat{k}_2 \cdot \hat{k}_1 \end{bmatrix} \begin{bmatrix} {}^2p_x \\ {}^2p_y \\ {}^2p_z \end{bmatrix}$$



$$\hat{i}_2 \cdot \hat{i}_1 = |\hat{i}_2| |\hat{i}_1| \cos \theta_3 = \cos \theta_3$$

$$\hat{j}_2 \cdot \hat{j}_1 = |\hat{j}_2| |\hat{j}_1| \cos \theta_3 = \cos \theta_3$$

$$\hat{k}_2 \cdot \hat{k}_1 = |\hat{k}_2| |\hat{k}_1| \cos 0^\circ = 1$$

$$\hat{j}_2 \cdot \hat{i}_1 = |\hat{j}_2| |\hat{i}_1| \cos(90^\circ + \theta_3) = -\sin \theta_3$$

$$\hat{k}_2 \cdot \hat{i}_1 = |\hat{k}_2| |\hat{i}_1| \cos 90^\circ = 0$$

$$\hat{i}_2 \cdot \hat{j}_1 = |\hat{i}_2| |\hat{j}_1| \cos(90^\circ - \theta_3) = \sin \theta_3$$


$$\hat{k}_2 \cdot \hat{j}_1 = |\hat{k}_2| |\hat{j}_1| \cos 90^\circ = 0$$

$$\hat{i}_2 \cdot \hat{k}_1 = |\hat{i}_2| |\hat{k}_1| \cos 90^\circ = 0$$

$$\hat{j}_2 \cdot \hat{k}_1 = |\hat{j}_2| |\hat{k}_1| \cos 90^\circ = 0$$

$$R_z(\theta_3) = \begin{bmatrix} \cos \theta_3 & \cos(90^\circ + \theta_3) & \cos 90^\circ \\ \cos(90^\circ - \theta_3) & \cos \theta_3 & \cos 90^\circ \\ \cos 90^\circ & \cos 90^\circ & \cos 0^\circ \end{bmatrix}$$

$$= \begin{bmatrix} \cos \theta_3 & -\sin \theta_3 & 0 \\ \sin \theta_3 & \cos \theta_3 & 0 \\ 0 & 0 & 1 \end{bmatrix} = \begin{bmatrix} c_{\theta_3} & -s_{\theta_3} & 0 \\ s_{\theta_3} & c_{\theta_3} & 0 \\ 0 & 0 & 1 \end{bmatrix}$$



$$i_2 \cdot i_1 = |i_2| |i_1| \cos 0 = 1$$

$$j_2 \cdot i_1 = 0$$

$$k_2 \cdot i_1 = 0$$

$$i_2 \cdot j_1 = 0$$

$$j_2 \cdot j_1 = \cos \theta$$

$$k_2 \cdot j_1 = -\sin \theta$$

$$i_2 \cdot k_1 = 0$$

$$j_2 \cdot k_1 = \sin \theta$$


$$k_2 \cdot k_1 = \cos \theta$$



Fundamental Rotation Matrix



Rotation about X



$i_2 \cdot i_1 = |i_2| |i_1| \cos 0 = 1$
 $j_2 \cdot i_1 = 0$
 $k_2 \cdot i_1 = 0$
 $i_2 \cdot j_1 = 0$
 $j_2 \cdot j_1 = \cos \theta$
 $k_2 \cdot j_1 = -\sin \theta$
 $i_2 \cdot k_1 = 0$
 $j_2 \cdot k_1 = \sin \theta$
 $k_2 \cdot k_1 = \cos \theta$

$$R_x(\theta_1) = \begin{bmatrix} 1 & 0 & 0 \\ 0 & \cos \theta_1 & -\sin \theta_1 \\ 0 & \sin \theta_1 & \cos \theta_1 \end{bmatrix} = \begin{bmatrix} 1 & 0 & 0 \\ 0 & C_1 & -S_1 \\ 0 & S_1 & C_1 \end{bmatrix}$$

Rotation about Y

$$R_y(\theta_2) = \begin{bmatrix} \cos \theta_2 & 0 & \sin \theta_2 \\ 0 & 1 & 0 \\ -\sin \theta_2 & 0 & \cos \theta_2 \end{bmatrix} = \begin{bmatrix} C_2 & 0 & S_2 \\ 0 & 1 & 0 \\ -S_2 & 0 & C_2 \end{bmatrix}$$






Mapping

Mapping

refers to changing the description of a POINT (or a vector) from one coordinate system (i.e. frame) to another coordinate system (i.e. frame).

Second coordinate frame has THREE possibilities in relation to the first coordinate frame

(i)	Second coordinate frame is rotated w.r.to the first but origin of both the frames is same	Mapping between Rotated frame	
(ii)	Second coordinate frame is moved away from first, the axes of both frames remains parallel. This is a translation of the origin of the second frame from the first frame.	Mapping between Translated frame	
(iii)	Second coordinate frame is rotated as well as translated	Mapping between Rotated & Translated frame	




Mapping



Mapping between Translated frame

Second coordinate frame is moved away from first, the axes of both frames remains parallel. This is a translation of the origin of the second frame from the first frame.



Considers two frames, frame {1} & frame {2} with origins O_1 & O_2 such that the axes of frame {1} are parallel to axes of frame {2}.

A pt. P in Space. Can be expressed as

Vector $\vec{O_2P}$ ($= {}^2P$) w.r. to frame {2}
Vector $\vec{O_1P}$ ($= {}^1P$) w.r. to frame {1}.

$$\vec{O_1P} = \vec{O_2P} + \vec{O_1O_2}$$

$${}^1P = {}^2P + {}^1D_2$$



Mapping




Mapping between Translated frame

Second coordinate frame is moved away from first, the axes of both frames remains parallel. This is a translation of the origin of the second frame from the first frame.

$$\vec{O_1P} = \vec{O_2P} + \vec{O_1O_2}$$

$${}^1P = {}^2P + {}^1D_2$$



$$\begin{aligned} {}^1p_x &= {}^2p_x + d_x = 1 \cdot {}^2p_x + 0 \cdot {}^2p_y + 0 \cdot {}^2p_z + d_x \\ {}^1p_y &= {}^2p_y + d_y = 0 \cdot {}^2p_x + 1 \cdot {}^2p_y + 0 \cdot {}^2p_z + d_y \\ {}^1p_z &= {}^2p_z + d_z = 0 \cdot {}^2p_x + 0 \cdot {}^2p_y + 1 \cdot {}^2p_z + d_z \end{aligned}$$

$${}^1P = \begin{bmatrix} 1 & 0 & 0 & d_x \\ 0 & 1 & 0 & d_y \\ 0 & 0 & 1 & d_z \\ 0 & 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} {}^2p_x \\ {}^2p_y \\ {}^2p_z \\ 1 \end{bmatrix}$$


$$D_2 = \begin{bmatrix} 1 & 0 & 0 \\ d_x & d_y & d_z \\ 0 & 0 & 1 \end{bmatrix}^T = \begin{bmatrix} d_x \\ d_y \\ d_z \\ 1 \end{bmatrix} \text{ in } \text{mm}$$



Mapping

$${}^1P = {}^1R_2 {}^2P + {}^1D_2$$

$${}^1P = {}^1T_2 {}^2P$$



Here, 1T_2 is 4×4 matrix referred to as the Homogeneous Transformation

or Homogeneous Transform.

- It describes both the position & orientation of frame w.r. to frame $\{1\}$

Homogeneous Transformation Matrix

$${}^1T_2 = \begin{bmatrix} \textcircled{{}^1R_2} & \textcircled{{}^1D_2} \\ i_2 \cdot i_1 & j_2 \cdot i_1 & k_2 \cdot i_1 & d_2 \\ i_2 \cdot j_1 & j_2 \cdot j_1 & k_2 \cdot j_1 & d_j \\ i_2 \cdot k_1 & j_2 \cdot k_1 & k_2 \cdot k_1 & d_k \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

Scale factor

$$= \begin{bmatrix} \text{Rotation Matrix} & \text{Translation Matrix} \\ (3 \times 3) & (3 \times 1) \\ \text{Perspective transformation matrix} & \text{Scale factor} \\ (1 \times 3) & (1 \times 1) \end{bmatrix} = \begin{bmatrix} {}^1R_2 & {}^1D_2 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$



Basic Homogeneous Transformation

Basic Homogeneous Rotation Transformation Matrix

or

Basic Homogeneous Rotation Matrix

or

Basic Homogeneous Transformation for Rotation

$$Rot(x, \theta_1) = \begin{bmatrix} 1 & 0 & 0 & 0 \\ 0 & c_1 & -s_1 & 0 \\ 0 & s_1 & c_1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

$\frac{y}{z}$
 $\Rightarrow R_{x, \theta_1}$

$$Rot(y, \theta_2) = \begin{bmatrix} c_2 & 0 & s_2 & 0 \\ 0 & 1 & 0 & 0 \\ -s_2 & 0 & c_2 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

$$Rot(z, \theta_3) = \begin{bmatrix} c_3 & -s_3 & 0 & 0 \\ s_3 & c_3 & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

Basic Homogeneous Translation Transformation Matrix

or

Basic Homogeneous Translation Matrix

or

Basic Homogeneous Transformation for Translation

$$Trans(x, d_1) = \begin{bmatrix} 1 & 0 & 0 & d_1 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

$$Trans(y, d_2) = \begin{bmatrix} 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & d_2 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

$$Trans(z, d_3) = \begin{bmatrix} 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & d_3 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$



Rotational matrix or Composite

Basic rule for finding Composite or Resultant Homogeneous transformation matrix

Rule 1: If the rotation (or transformation) of a frame is about ^{axis of} fixed reference frame then the overall/resultant ^{homogeneous} transformation matrix is computed by PRE-MULTIPLICATION of the basic homogeneous transformation matrix.

Case(I) (i) $R = R_{1,90^\circ} R_{2,90^\circ}$

(ii) $R = R_{2,90^\circ} \cdot R_{1,90^\circ}$

Case(I) (i) $R = R_{1,90^\circ} R_{2,90^\circ}$


(ii) $R = R_{2,90^\circ} \cdot R_{1,90^\circ}$

Rule 2:

$T = Rot(1, 90^\circ) Rot(2, 90^\circ)$

$T = Rot(2, 90^\circ) Rot(1, 90^\circ)$

If rotation (or transformation) of a frame is about its own axis then the overall/resultant homogeneous transformation matrix is computed by POST-MULTIPLICATION of the basic homogeneous transformation matrix



Case(II) (i) $R = R_{2,90^\circ} \cdot R_{1,90^\circ}$

(ii) $R = R_{1,90^\circ} \cdot R_{2,90^\circ}$



Composite Homogeneous Transformation Matrix

Composite Transformation 1



fig: Composite Transformation of Three frames

- Three frames, with each frame rotated & translated from its preceding frame.
- It is proposed to find the transform, which relates 3P in frame $\{3\}$ to 1P in frame $\{1\}$.

The transformation matrix 2T_3 can be used to map 3P , the pt. 'P' in frame $\{3\}$ to frame $\{2\}$

$${}^2P = {}^2T_3 \cdot {}^3P$$

Similarly

$${}^1P = {}^1T_2 \cdot {}^2P$$

$$\therefore {}^1P = {}^1T_2 ({}^2T_3 \cdot {}^3P)$$

$$\therefore {}^1P = {}^1T_2 \cdot {}^2T_3 \cdot {}^3P$$

$$\text{Hence } {}^1P = {}^1T_3 \cdot {}^3P$$

$\therefore$ The overall transformation betⁿ frame $\{3\}$ & frame $\{1\}$ is obtained



$${}^1T_3 = {}^1T_2 \cdot {}^2T_3$$

It is easily follow that the Transformation from frame $\{1\}$ to frame $\{3\}$ -

$${}^1T_3 = {}^1T_2 \cdot {}^2T_3 \dots \dots \dots {}^nT_1$$





Commonly used Industrial Robotic Manipulator



Commonly Joints used in Robotic Manipulator

Linear joint (P)

Rotary joints (R)





Numbering Convention of Link, Joint & Frame





An 'n' DOF robotic arm consists of (n+1) links (including fixed link i.e, base or link 0) connected by 'n' joints of 1 DOF each

Link number: 0 to n

Joint number: 1 to n


Frame number or Axis no. 0 to n



A frame {i} is rigidly attached to distal joint [i.e., joint (i+1)] of link 'i' & it moves with link 'i':



Denavit-Hartenberg (DH) Notation





Denavit-Hartenberg (DH) Notation

A frame {i} is assigned to distal joint [i.e., joint (i+1)] of link 'i' as follows:

1. The z_i axis is aligned with axis of joint (i+1) [i.e., (i+1)th joint axis].

The positive direction of the z_i axis is arbitrary.

2. The x_i axis is defined along the common normal between the z_{i-1} and z_i axis & pointing from the z_{i-1} to the z_i axis.

[Common normal has the shortest distance between the two skew lines]

The origin of frame {i} rigidly attached to the link 'i' is located at the intersection of z_i & x_i axis

Three more possible cases:


Case (i) when the two consecutive z-axes (z_{i-1} and z_i) are intersecting, then x_i -axis will be perpendicular to the plane formed by z_{i-1} and z_i axes in the direction of $z_{i-1} \times z_i$


The origin of frame {i} is located at the point of their intersection

Case (ii) when the two consecutive z-axes (z_{i-1} and z_i) are parallel, then there are an infinite number of common normal. You may consider any one. But prefer to choose that common normal which is passing through origin of frame {i-1}

Case (iii) when the two consecutive z-axes (z_{i-1} and z_i) are collinear, then x_i -axis is chosen parallel to previous x axis i.e, x_{i-1}


3. Finally, the y_i -axis is determined by the RH rule (i.e., $y_i = z_i \times x_i$)








Denavit-Hartenberg (DH) Notation





Link parameters

Determine the structure of the link

Joint parameters

Determine the relative position of neighboring links.



D-H parameters or Joint-link parameters

Link parameters

Link length (a_i) of Link 'i'

- Shortest distance (along common normal) between two motion axes of a link 'i'
- Distance between z_{i-1} & z_i axes along the x_i – axis.

NB: Link length is not the physical length of the rigid link rather it is perpendicular distance between two axes of the binary link

Always POSITIVE

Link twist (α_i) of Link 'i'

- The angle between projection of axis (i-1) and axis i on a plane perpendicular to the common normal.
- Angle between z_{i-1} & z_i axes measured from z_{i-1} about x_i – axis in RH sense.
- or required rotation of the z_{i-1} axis about the x_i – axis to become parallel to the z_i axis

Sign convention: RH rule [CCW (+), CW (-)]

D-H parameters or Joint-link parameters

Joint parameters

Joint distance (d_i) of joint 'i'


- The perpendicular distance between two adjacent common normal measured along motion axis of joint 'i'
- The distance between x_{i-1} & x_i axes along the z_{i-1} axis.


Signed quantity

Joint angle (θ_i) of joint 'i'

- The angle between the two adjacent common normal about axis of joint 'i' in RH sense
- Angle between x_{i-1} & x_i axes measured from x_{i-1} about positive z_{i-1} in RH sense.
- or required rotation of the x_{i-1} axis about the z_{i-1} - axis to become parallel to the x_i axis

Sign convention: RH rule [CCW (+), CW (-)







Fixed parameters

- Both Link parameters

Variable parameters

- Either of two joint parameters







Kinematic Relationship between adjacent links of a manipulator

The transformation of frame $\{i-1\}$ to frame $\{i\}$ consists of four basic transformations as shown in Fig. 3.9.

A rotation about z_{i-1} -axis by an angle θ_i ;

$$\begin{bmatrix} \cos \theta_i & -\sin \theta_i & 0 & 0 \\ \sin \theta_i & \cos \theta_i & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

Translation along z_{i-1} -axis by distance d_i ;


$$\begin{bmatrix} 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & d_i \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

Translation by distance α_i along x_i -axis,

$$\begin{bmatrix} 1 & 0 & 0 & \alpha_i \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

Rotation by an angle α_i about x_i -axis.

$$\begin{bmatrix} 1 & 0 & 0 & 0 \\ 0 & \cos \alpha_i & -\sin \alpha_i & 0 \\ 0 & \sin \alpha_i & \cos \alpha_i & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$



Each of these four operations can be expressed by a basic homogeneous rotation-translation matrix and the product of these four basic homogeneous transformation matrices yields a composite homogeneous transformation matrix,

$${}^{i-1}T_i = \begin{bmatrix} \cos \theta_i & -\sin \theta_i & 0 & 0 \\ \sin \theta_i & \cos \theta_i & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} 1 & 0 & 0 & 0 \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & d_i \\ 0 & 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} 1 & 0 & 0 & \alpha_i \\ 0 & 1 & 0 & 0 \\ 0 & 0 & 1 & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix} \begin{bmatrix} 1 & 0 & 0 & 0 \\ 0 & \cos \alpha_i & -\sin \alpha_i & 0 \\ 0 & \sin \alpha_i & \cos \alpha_i & 0 \\ 0 & 0 & 0 & 1 \end{bmatrix}$$


$${}^{i-1}T_i = \begin{bmatrix} \cos \theta_i & -\cos \alpha_i \sin \theta_i & \sin \alpha_i \sin \theta_i & a_i \cos \theta_i \\ \sin \theta_i & \cos \alpha_i \cos \theta_i & -\sin \alpha_i \cos \theta_i & a_i \sin \theta_i \\ 0 & \sin \alpha_i & \cos \alpha_i & d_i \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

D-H transformation matrix

link i transformation matrix.



Kinematic Relationship between adjacent links of a manipulator



D-H transformation matrix

link i transformation matrix.

$${}^{i-1}T_i = \begin{bmatrix} C\theta_i & -S\theta_i C\alpha_i & S\theta_i S\alpha_i & a_i C\theta_i \\ S\theta_i & C\theta_i C\alpha_i & -C\theta_i S\alpha_i & a_i S\theta_i \\ 0 & S\alpha_i & C\alpha_i & d_i \\ 0 & 0 & 0 & 1 \end{bmatrix}$$


where $C\theta_i = \cos \theta_i$, $S\theta_i = \sin \theta_i$, $C\alpha_i = \cos \alpha_i$, and $S\alpha_i = \sin \alpha_i$.

$${}^{i-1}T_i = \begin{bmatrix} C\theta_i & -S\theta_i C\alpha_i & S\theta_i S\alpha_i & a_i C\theta_i \\ S\theta_i & C\theta_i C\alpha_i & -C\theta_i S\alpha_i & a_i S\theta_i \\ 0 & S\alpha_i & C\alpha_i & d_i \\ 0 & 0 & 0 & 1 \end{bmatrix}$$

The homogeneous transformation matrix ${}^{i-1}T_i$ describes the position and orientation of frame $\{i\}$ relative to frame $\{i-1\}$ and completely specifies the geometric relationship between these links in terms of four DH-parameters ($\theta_i, d_i, \alpha_i, a_i$). Of these four parameters, only one is a variable for link i , the displacement variable q_i (θ_i or d_i) and other three are constant. The matrix ${}^{i-1}T_i(q_i)$ is known as link i transformation matrix. As shown before, the 3×3 upper left corner submatrix of Eq. (3.5) gives the orientation of coordinate axes of frame $\{i\}$, while the 3×1 upper right corner sub-matrix represents the position of the origin of frame $\{i\}$.



Robot Arm Kinematics






Forward or Direct Kinematics Robotic Arm




Main Steps in Forward Kinematics of Robotic Arm

- Step 1** - Choose suitable home position & Draw Kinematic diagram
- Step 2** - Numbering the links (0 to n), numbering the joint (1 to n) & identify the motion axis
- Step 3** - Assign RH frame to each link of the robotic manipulator arm starting from base to the end,, based on DH notation
- Step 4** - Write or prepare D-H parameters table .
- Step 5** - Evaluate individual Link Transformation Matrix or DH transformation matrix of all links (i.e., ${}^0T_1, {}^1T_2, {}^2T_3, \dots, {}^{n-1}T_n$)
- Step 6** - Evaluate Composite HTM or Manipulator Arm Transformation Matrix (0T_n).





MANIPULATOR TRANSFORMATION MATRIX




The position and orientation of the tool frame relative to the base frame can be found by considering the n consecutive link transformation matrices relating frames fixed to adjacent links. Thus,

$${}^0T_n = {}^0T_1(q_1) {}^1T_2(q_2) \dots {}^{n-1}T_n(q_n) \quad (3.6)$$

where ${}^{i-1}T_i(q_i)$ for $i = 1, 2, \dots, n$ is the homogeneous link transformations matrix between frames $\{i-1\}$ and $\{i\}$ and is given by Eq. (3.5).



$${}^0T_n = {}^0T_1 {}^1T_2 \dots {}^{n-1}T_n$$


Forward or Direct Kinematics of 3 DOF spatial robotic arm




Step 1 - Choose suitable home position & Draw Kinematic diagram

Step 2 - Numbering the links (0 to n), numbering the joint (1 to n) & identify the motion axis











Step 3

- Assign RH frame to each link of the robotic manipulator arm starting from base to the end, based on DH notation



Step 4

- Write or prepare D-H parameters table .

Link no., Joint no., Frame no. (i)	Link length (a_i)	Link twist (α_i)	Joint distance (d_i)	Joint angle (θ_i)
1	$a_1=0$	$\alpha_1=90$	$d_1=95$	θ_1 (JV)
2	$a_2=100$	$\alpha_2=0$	$d_2=0$	θ_2 (JV)
3	$a_3=75$	$\alpha_3=0$	$d_3=0$	θ_3 (JV)